



# Bose SoundLink Mini II Battery Replacement

This guide will help users replace/disassemble the battery of the Bose Soundlink Mini II.

Written By: Devon



## INTRODUCTION

Speaker not turning on? This guide will help you replace the battery of the Bose Soundlink Mini II.

---



### TOOLS:

- [T9 Torx Screwdriver](#) (1)
  - [64 Bit Driver Kit](#) (1)
-

## Step 1 — Battery



- Flip the speaker over onto its back.

## Step 2



- Gently remove the rubber base from speaker by pulling around the edges.





## Step 3



- Remove the four 6mm T9 Torx bit screws from the corners of the battery.

## Step 4



- Gently remove the battery from the speaker.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-11 01:08:54 PM.